






PARTS DETAILS



G65

#	Part Description	Part#	G22	SB84	G34	S68	G44	S62
1	Needle Cap		■	■	■	×	×	×
2	Nozzle Cap		■	■	■	×	×	×
3	O-Ring for Nozzle Cap		■	■	■	×	×	×
4	Nozzle		■	■	■	×	×	×
5	O-Ring		■	■	■	×	×	×
6	Lid for Color Cup		■	×	×	×	×	×
7	Operation Lever		■	■	■	×	×	×
6A	Airbrush Body		■	×	×	×	×	×
6B	Airbrush Body		×	■	×	×	×	×
6C	Airbrush Body		×	×	×	×	×	×
6D	Airbrush Body		×	×	×	■	×	×
6E	Airbrush Body		×	×	×	×	■	×
6F	Airbrush Body		×	×	×	×	×	■
8	O-Ring		■	■	■	×	×	×
9	Needle Guide		■	■	■	×	×	×
10	Needle Chucking Guide		■	■	■	×	×	×
11	Spring		■	■	■	×	×	×
12	Needle		■	■	×	×	×	×
13	Standard-Handle Adjusting		■	×	×	×	×	×
14	Needle Chucking Net		■	■	■	×	×	×
15	Spring Case		■	■	■	×	×	×
16	Nozzle Spanner		■	■	■	×	×	×
17	Standard-Handle Adjusting		×	■	■	×	×	×
18	Adjusting Screw		×	■	■	×	×	×
19	Nut for color cup		×	■	×	×	×	×
20	O-Ring		×	■	×	×	×	×
21	Color Cup		×	■	×	×	×	×
22	O-Ring		×	■	■	×	×	×
23	Glass Jar		×	■	×	×	×	×
24	Lever Guide O-Ring		■	■	■	×	×	×
25	Valve O-Ring		■	■	■	×	×	×
26	Valve Body		■	■	■	×	×	×
27	Valve Rod O-Ring		■	■	■	×	×	×
28	Valve Rod		■	■	■	×	×	×
29	Valve Spring		■	■	■	×	×	×
30	Valve Screw		■	■	■	■	×	×
31	Protective Cap		×	×	×	■	×	×
32	Air Cap		×	×	×	■	×	×
33	O-Ring		×	×	×	■	×	×
34	Nozzle		×	×	×	■	×	×
35	O-Ring		×	×	×	■	×	×
36	Air Cap Body		×	×	×	■	×	×
37	O-Ring		×	×	×	■	×	×
38	Adjustment Screw		×	×	×	■	×	×
39	Finger lever		×	×	×	■	×	×
40	Standard-Handle Adjusting		×	×	×	■	×	×
41	O-Ring		×	×	×	■	×	×
42	O-Ring		×	×	×	■	×	×
43	Valve Body		×	×	×	■	×	×
44	Valve Rod		×	×	×	■	×	×
45	Valve Rod O-Ring		×	×	×	■	×	×
46	Valve Spring		×	×	×	■	×	×
47	Valve Screw		×	×	×	■	×	×
48	Needle		×	×	×	■	×	×
49	Head Cap Spanner		×	×	×	■	×	×
50	22 cc Glass jar assembly		×	×	×	■	×	×

G65

#	Part Description	Part#	G22	SB84	G34	S68	G44	S62
51	Needle Cap		x	x	x	x	■	x
52	Nozzle Cap		x	x	x	x	■	x
53	Nozzle		x	x	x	x	■	x
54	O-Ring for Nozzle Cap		x	x	x	x	■	x
55	Air cap Body		x	x	x	x	■	x
56	O-Ring		x	x	x	x	■	x
57	O-Ring		x	x	x	x	■	x
3A	Airbrush Body		x	x	x	x	■	x
3B	Airbrush Body		x	x	x	x	■	x
3C	Airbrush Body		x	x	x	x	■	x
58	Lid for Color Cup		x	x	x	x	■	x
59	Operation Lever		x	x	x	x	■	x
60	O-Ring for Needle Guide		x	x	x	x	■	x
61	Needle Guide		x	x	x	x	■	x
62	Needle Chucking Guide		x	x	x	x	■	x
63	Spring		x	x	x	x	■	x
64	Needle Chucking Net		x	x	x	x	■	x
65	Spring Case		x	x	x	x	■	x
66	O-Ring		x	x	x	x	■	x
67	Linker		x	x	x	x	■	x
68	Needle		x	x	x	x	■	x
69	Standard-Handle Adjusting		x	x	x	x	■	x
70	Bush		x	x	x	x	■	x
71	O-Ring		x	x	x	x	■	x
72	Adjusting Screw		x	x	x	x	■	x
73	Lever Guide O-Ring		x	x	x	x	■	x
74	Valve O-Ring		x	x	x	x	■	x
75	Valve Body		x	x	x	x	■	x
76	Valve Rod O-Ring		x	x	x	x	■	x
77	Valve Rod		x	x	x	x	■	x
78	Valve Spring		x	x	x	x	■	x
79	Valve Screw		x	x	x	x	■	x
80	O-Ring		x	x	x	x	■	x
81	Setscrew		x	x	x	x	■	x
82	O-Ring		x	x	x	x	■	x
83	Adjuster		x	x	x	x	■	x
84	Needle Cap		x	x	x	x	x	■
85	Nozzle Cap		x	x	x	x	x	■
86	Head Cap		x	x	x	x	x	■
87	O-Ring		x	x	x	x	x	■
88	Nozzle		x	x	x	x	x	■
6F	Airbrush Body		x	x	x	x	x	■
89	Operation Lever		x	x	x	x	x	■
90	O-Ring for Needle Guide		x	x	x	x	x	■
91	Needle Guide		x	x	x	x	x	■
92	Needle Chucking Guide		x	x	x	x	x	■
93	Spring		x	x	x	x	x	■
94	Spring Case		x	x	x	x	x	■
95	Needle Chucking Net		x	x	x	x	x	■
96	Standard-Handle Adjusting		x	x	x	x	x	■
97	O-Ring		x	x	x	x	x	■
98	Adjusting Screw		x	x	x	x	x	■
99	O-Ring		x	x	x	x	x	■
100	O-Ring		x	x	x	x	x	■
101	Air valve Guide Body		x	x	x	x	x	■
102	Valve Rod O-Ring		x	x	x	x	x	■
103	Valve Rod		x	x	x	x	x	■
104	Valve Spring		x	x	x	x	x	■
105	Valve Screw		x	x	x	x	x	■
106	Needle		x	x	x	x	x	■
107	Head Cap Spanner		x	x	x	x	x	■
108	22 cc Glass jar assembly		x	x	x	x	x	■